






-  Freely programmable LED keys P1 - P27
-  Default setting: Line
-  Other settings: Speed Dial, Transfer to, BLF (Busy Lamp Field)

Steadily lit Green = Available  
 Steadily lit Red = Occupied  
 Blinking Red = Incoming Call



- History:** Call history (missed, received, dialed calls)
- Directory:** LDAP and Local Phonebook
- DND:** Turn DND (do not disturb) on/off
- Menu:** Open the Phones Main Menu

## Yealink T46S with peoplefone



### Call pick up

By pushing a LED key (P1 - P27) programmed as BLF or  +  + internal number of the ringing device.

### Call transfer - Attended transfer

Put the call on hold with the  key, then dial the number that you wish to transfer to. If the third party wishes to accept the call, press .

### Call transfer - Blind transfer

While in the call, press  then dial the number that you wish to transfer to and press  again.

### Setup a Forwarding

Press the Menu Key (Display 4) -> Select "Features" -> "Call Forward" -> Choose which rule you want to change -> Set a number to forward to -> Switch the status to "Enabled"



### Disable a Forwarding

Same steps as above, except the status is set to "Disabled".  
 This just deactivates it, for simple reactivation later.

### Change the used Identity

Use the left  and right  direction keys to cycle through the different identities of the phone

### Reboot the phone

Hold the  for several seconds and confirm by pressing 

### Factory Reset

Hold the  key seconds and confirm by pressing  again